



Product End-of-Life Disassembly Instructions

Product Category: Scanners

Marketing Name / Model

[List multiple models if applicable.]

HP Digital Sender Flow 8500 fn2 / L2762A

HP ScanJet Enterprise Flow N9120 fn2 / L2763A

Purpose: The document is intended for use by end-of-life recyclers or treatment facilities. It provides the basic instructions for the disassembly of HP products to remove components and materials requiring selective treatment, as defined by EU directive 2002/96/EC, Waste Electrical and Electronic Equipment (WEEE).

1.0 Items Requiring Selective Treatment

1.1 Items listed below are classified as requiring selective treatment.

1.2 Enter the quantity of items contained within the product which require selective treatment in the right column, as applicable.

Item Description	Notes	Quantity of items included in product
Printed Circuit Boards (PCB) or Printed Circuit Assemblies (PCA)	With a surface greater than 10 sq cm	11
Batteries	All types including standard alkaline and lithium coin or button style batteries	1
Mercury-containing components	For example, mercury in lamps, display backlights, scanner lamps, switches, batteries	0
Liquid Crystal Displays (LCD) with a surface greater than 100 sq cm	Includes background illuminated displays with gas discharge lamps	1
Cathode Ray Tubes (CRT)		0
Capacitors / condensers (Containing PCB/PCT)		0
Electrolytic Capacitors / Condensers measuring greater than 2.5 cm in diameter or height		0
External electrical cables and cords	USB cable and power cord	2
Gas Discharge Lamps		0
Plastics containing Brominated Flame Retardants weighing > 25 grams (not including PCBs or PCAs already listed as a separate item above)		0
Components and parts containing toner and ink, including liquids, semi-liquids (gel/paste) and toner	Include the cartridges, print heads, tubes, vent chambers, and service stations.	0
Components and waste containing asbestos		0
Components, parts and materials containing refractory ceramic fibers		0

Components, parts and materials containing radioactive substances		0
---	--	---

2.0 Tools Required

List the type and size of the tools that would typically be used to disassemble the product to a point where components and materials requiring selective treatment can be removed.

Tool Description	Tool Size (if applicable)
Torx screw driver	T6, T8, T10
Phillips screw driver	
Scissors	
Combination plier	
Needle nose plier	

3.0 Product Disassembly Process

3.1 List the basic steps that should typically be followed to remove components and materials requiring selective treatment:

1. Dettach ADF assembly from scanner bed. Dimantle and sort according to material type and marking.
2. Remove scanner glass bed and scan bar from the scanner base. Be cautious when handling glass scanner bed.
3. Remove and dissamble control panel from front case part. Set aside LCD greater than 100 sq cm for selective treatment.
4. Dismantle the scanner base. Remove main PCA, coin cell battery from main PCA and internal power supply for selective treatment. Sort plastic case parts according to material marking.
- 5.
- 6.
- 7.
- 8.
- 9.
- 10.
- 11.

3.2 Optional Graphic. If the disassembly process is complex, insert a graphic illustration below to identify the items contained in the product that require selective treatment (with descriptions and arrows identifying locations).

